



APIKOL URS4/S6 REAR SUBFRAME BUSHING INSTALLATION INSTRUCTIONS



Estimated Installation Time: Approximately 2 hours

Bushing Installation Instructions:

- 1) The rear subframe needs to be removed from the car so the stock bushings can be pressed out. The stock bushings need to be pushed out from the top down. You will need to use a press to get the old bushings out.
- 2) After the stock bushings have been removed you are ready to put the new Apikol bushings in. Install the urethane bushings from either side first. Dish soap works well as a lubricant to help the bushings slide into place by hand.
- 3) Once the bushings are in place you can slide the aluminum center sleeves into place. Again, dish soap will help them to go into place. Methods to do this include using either a press or vice. If you do not have access to either of these tightening a bolt with large washers on either end will work as well.
- 4) Reinstall the rear subframe and enjoy your new subframe bushings.